

Egalfloor Fini 5mm

Egalfloor Fini is a durable bitumen wood fibre board of pine trees, suitable for the installation of floating vinyl in a domestic areas.

- Fast and easy to install
- High pressure resistance
- Good impact sound reduction
- High smoothening capacity

Installation method: Floating installation in brick wise fashion on top of a moisture barrier of 150-200 micron.

Thickness: 5 mm / \pm 0.5 mm

Dimension: 800mm x 570mm \pm 2-5mm/m

Weight: 1550 gr/m² / \pm 155 gr/m²

Density: 300 kg/m³ / \pm 30 kg

Material: 90% wood fibres (pine)
10% bitumen without harmful additives

Packing:	Material	Made of recycable hdpe foil
	Contens / packs	22 boards / 10,03 m ²
	Contens / pallet	20 packs / 200,6 m ²
	Dimension / pallet	1200 x 800 x 1240 - h x w x h in mm
	Weight / pallet	342 kg

Technical data:

Colour	: Green
Durability / Swelling after 2hrs (Test ing method: EN 317)	: ± 6%
moisture contents (Testing medhod: EN 322)	: ± 6-12%
Castor wheel chair use (Testing method: EN 985)	: Suitable
Inpact sound reduction (Testing method: NEN-EN ISO 140-8)	: 18dB ΔLw
Smoothing Capacity (Testing method: NA)	: Good
Heat resistance (Testing method: ISO 8302)	: 0.071 m ² K/W
Vapour resistance (Testing medhod: ISO 12572:2001)	: Sd0,02m
Fire classification (Testing method: EN 13501-1)	: Efl
Formaldehyde (Testing nethod: EN 120)	: E-1

Installation Instuctions:

- Soft board is a natural product. It has to acclimatise in its original packing for at least 24 hours in te room to be installed..
- The ideal temperure is 15-20C. And the humidity approx. 50-70%
- Make sure that the floor is dry and free of dust and grit.
- Always install a moisture proof foil of at least 150-200 micron and overlap thje seams approx. 20cm. Seams to be taped with adhesive tape.
- Install the soft board in brick wise fashion. Leave approx. 2 mm space between the board and approx. 8mm next to walls and other objects like heating pipes ect.

Important for use:

- To limit impressions of vinyl, you should, for example, to put protective felt under the legs of furniture. Egalfloor Fini, however, can not prevent the impression in the vinyl.
- The total construction must at all times be provided with a moisture barrier. If there is already a moisture barrier under the wooden floor (crawl space), you should not use a moisture barrier under Egalfloor Fini i.v. locking up moisture. Your crawl space must always be adequately ventilated.

When the installation instuctions are not respected, Estillon can not be held responsible for any damage or claims due to and as a result of incorrect intsallation. In case of doubt always consult your supplier.

