

Roma 6.9mm

Roma is a carpet underlay produced from ribbed sponge rubber. The heavy sponge rubber creates a stable and durable base for every carpet. Roma delivers a maximum contribution to the experience of luxury and comfort of the carpet. Roma is suitable for domestic and H.D. contract applications.

- Stable base for installation and easy process
- smoothening small unevennesses in the subfloor
- Extends the lifetime and original appearance of the carpet
- Offers comfort and experience of luxury
- Excellent for impact sound reduction

Installation method : Install Roma with the crepe paper topside. Roma is suitable for the stretching method.

Direction of installation method Always install the underlay in a 90 angle underneath the length of the carpet in order to avoid matching of seams in underlay and carpet.

General building inspection license: NA

Thickness: 6,9 mm / $\pm 0,7$ mm - maximum tolerance 10%

Dimensions: 7,33m x 1,37m = ± 10 m²

Weight: 3087 gr/m² / ± 309 gr/m² (31 kg/roll) - maximum tolerance 10%

Density: 447 kg/m³ / $\pm 44,7$ kg - maximum tolerance 10%

Material: Top Layer : Stitch bonded perforated crepe paper

Bottom Layer : Ribbed sponge Rubber

Packing: Material : Printed LDPE foil (no core) with insert sheet

Technical information:

Dimensional stability Traction	: 40 N/mm ² / length 192N / width 129N
Dimensional stability extension: (test method: ISO 13934-1)	: 10% / length 4,1% / width 2,9%
Caster chair test (Test method: EN 985)	: NA
Impact sound reduction (Test method: NA)	: $\Delta L_w = 31$ dB
Thermal resistance (Test method: NA)	: 0,8 togs - 0,08 m ² K/W
Fire retardancy (Test methode: EN ISO 9239-1)	: Efl
ASTM radial panel test (Test methode: ASTM E 648-06)	: NA
Russian requirements on fire safety (Test methode: FZ-123)	: NA

Installation instructions:

- Let the carpet as well as the underpadding acclimatise for 24 hours in the original packing in the room to be installed.
- The best temperature for installation is 5-20°C. and a humidity of 50-70%.
- make sure that the underfloor is absolutely dry and free of grit and dust.
- To cut the underpadding we recommend to use a trapezium blade.
- Underpadding can not prevent the natural shrinkage of carpet.
- Always follow the installation instructions of the carpet Manufacturer.
-

Important:

In case the installation has not been done in accordance with the installation instructions, estillon can not be held responsible for any damage or claim as a result of an incorrect installation. In case of doubt always consult your supplier.

