## R914 / 55-65-75-85-95



Needle felt underpadding for a durable installation. The padding consist of needle punched recycled textile fibres. R914 is applicable for domestic use. Also to use for stair protection felt.

- · High smoothening capacity
- Good compression recovery capacity
- Prolongs the lifetime of the carpet

Installation method	: For	stretched or	double stic	k installation.

NA

**Direction of installation method**Always install the underlay in a 90° angle underneath the length of the carpet in

order to avoid matching of seams in underlay and carpet.

General building inspection license:

neense.

**Thickness:** 5 mm /  $\pm$  0,5 mm - maximum tolerance 10%

Dimensions:  $30m \times 0,55m = \pm 16,5m^2$  $30m \times 0,65m = \pm 19,5m^2$ 

 $30m \times 0.75m = \pm 22.5m^2$   $30m \times 0.85m = \pm 25.5m^2$  $30m \times 0.95m = \pm 28.5m^2$ 

Weight: 600 gr/m<sup>2</sup> / ± 60 gr/m<sup>2</sup> (51 kg/roll) - maximum tolerance 10%

**Density:**  $150 \text{ kg/m}^3 / \pm 15 \text{ kg} - \text{maximum tolerance } 10\%$ 

Material: Layer: Needle punched recycled textile fibres.

Coated on one side

Packing: Material: Transparant LDPE foil (no core).



# R914 / 55-65-75-85-95



#### Technical information:

Dimensional stability Traction : NA

Dimensional stability extension: : NA

(test method: ISO 13934-1

Caster chair test : none

(Test method: EN 985)

Impact sound reduction : NA

(Test method: NA)

Thermal resistance : NA

(Test method: NA)

Fire retardency : NA (Test methode: EN ISO 9239-1)

ASTM radial panel test : NA (Test methode: ASTM E 648-06)

Russian requirements on fire safety : NA

(Test methode: FZ-123)

#### Installation instructions:

- Let the carpet as well as the underpadding acclimatise for 24 hours in the original packing in the room to be installed.
- The best temperature for installation is 5-20°C. and a humidity of 50-70%.
- make sure that the underfloor is absolutely dry and free of grit and dust.
- $\bullet\,$  To cut the underpadding we recommend to use a scissor.
- Underpadding can not prevant the natural shrinkage of carpet. Always follow the installation instructions of the carpet Manufacturer.

### Important:

In case the installation has not been done in accordance with the installation instructions, estillon can not be held responsible for any damage or claim as a result of an incorrect installation. In case of doubt always consult your supplier.







