

Floorfixx fini is a system floor that helps correct minor underlay irregularities. The self-adhesive lap joint will help you to quickly and easily create a new, insulating and even underlay that can bear load immediately. Floorfixx fini is ideal for household and light commercial applications

- Renovation of poor basic floors for rigid core, carpet tiles, vinyl flooring, and PVC click flooring
- No waiting or drying time and it can bear load immediately
- Self-adhesive lap joint
- Levels out unevenness
- Maximum stability
- Extends the service life of carpet tiles, vinyl flooring, and PVC click flooring
- Insulates against impact noise and meets the 10 dB standard set by the Owners' Association

Installation method: Floating. Fast and easy to install thanks to the 50mm self-adhesive overlap-joint construction

Thickness: 8 mm

Dimension: 850 mm x 590 mm ± 1,5 mm/m

Weight a m²: 2880 gram/m² / ± 288 gr/m²

Density: 360 kg/m³ / ± 36 kg

Material:
Top layer : 3 mm MDF
Bottom layer : 5 mm XPS foam

Packaging:
Material : Recycled LDPE foil with installation instructions
Pack content : 10 sheets / 5,015 m²
Pallet content : 30 packs / 150,45 m²
Pallet dimension : 900 x 1300 x 1350 - (L x W x H in mm)
Pallet weight : 488,29 kg



floorfixx fini
made in Holland by estillon

Technical specification:

Bending strength (Test method: EN 310)	: 39 N/mm ²
Castor chair use (Test method: EN 985)	: Suitable
Impact sound reduction (Test method: NEN-EN ISO 717-2)	: $\Delta L_w = 21$ dB
Levelling capabilities (Test method: NA)	: Good
Togg value (test method: ISO 8302)	: 2,13 toggs
Flammability (Test method: EN 13501-1)	: Efl-S1
Formaldehyde (Test method: EN 120)	: E-1

Installation instruction:

- Before installation the product needs to acclimatize 48 hours in closed packaging in the area where it will be installed.
- The humidity needs to be 50 - 70 % and the ideal temperature for installation is 15 - 20°C .
- The surface has to be free of dust and completely dry before installation.
- Always install a 150 - 200 μ m thick moisture barrier on the floor and leave a 2" foil excess up to the skirting/wall. The joints of the moisture barrier have to overlap with 8-10" and have to be taped.
- Install Floorfixx fini floating in stretcher bond with the MDF side faced up. The first row needs to be cut two length wise (29,5 x 85 cm) and the second row must be started using half a board (59 x 42,5 cm).
- Slide the boards against each other, the pre tackified lip-las construction ensures a stable and strong fixation. The overlap connection has to be tapped firmly with a rubber mallet.
- On wood plank floors it is recommended to install the Floorfixx fini boards diagonally in the room.
- Leave 1 cm free space next to walls and other fixed/permanent objects for possible elongation. A kitchen is a fixed object and must be placed on the original subfloor.
- When the installation requires the vinyl to fixed to the subfloor, we recommend using double sided tape. In case adhesives are required we advise to use Floorfixx smart, because Floorfixx fini is not suitable for a wet bond.
- If the installation area is larger/wider then 10 meter a dilatation joint must be created in both Floorfixx fini and the floorcovering.
- To ensure a smooth surface make sure the seams of Floorfixx fini are hand sanded.
- Install the floorcovering within 24 hours after the installation of Floorfixx fini.

Important :

Do not use a wet bond method, because the moisture can cause telegraphing issue due to swelling of the MDF board surface and edges!
Floorfixx fini can not be used in humid area's!
Work clean and make sure that the pre-glued lip-las construction of Floorfixx fini remains free of dirt and dust

Installation advise:

Floorfixx fini is easy to cut with a Laminate & PVC Cutter & EC 320/EC 18V Mini Saw.

When the installation instructions are not followed, Estillon can not be held responsible for damage and / or claims as a result of incorrect installation. If you are in doubt, please always ask your supplier for advice. .