

Universal Stop 2,5mm

Universal Stop is a non-skid rug underlay for under rugs, produced out of a recycled polyester, suitable for application on wall to wall carpet, parquet, laminate, ceramic tiles, cork and LVT. This light weight rug underlay does not contain any softeners and creates a good and solid base for any rug and emphasize the luxury and comfort of the rug. Universal Stop is suitable for domestic and commercial use.

- Light weight and easy to install
- Levels out small irregularities in the subfloor
- Produced environmental friendly
- Suitable in combination with floor heating

Installation method:

Install Universal Stop underneath the rug and make sure that Universal Stop is resized 50mm smaller than the backing of the rug. Carpet Backing: light grey side to the carpet, black to the floor.
Universal Stop on Laminate: Black side to the floor.
Universal Stop on carpet: light grey side to the floor

Direction of installation method: NA

General building inspection license: NA

Thickness: 2,5 mm / $\pm 0,25$ mm - maximum tolerance 10%

Dimensions:

50m x 3m	= 150m ²
50m x 2,4m	= 120m ²
70cm x 190cm	= 19,95m ²
160cm x 230cm	= 25,76m ²
130cm x 190cm	= 19,76m ²
190cm x 290cm	= 27,55m ²

Weight: 240 gr/m² / ± 24 gr/m²

Material: Top Layer : 85% polyester made from recycled polyester which is made from "recycled fibres post-consumer waste and post-industrial waste"
15% "new fibres"

Packing: Material : Transparant LDPE foil

Universal Stop 2,5mm

Technical information:

<i>Punctual conformity</i>	: NA
<i>Compressive strenght</i> (test method: EN 826 + Annex a)	: NA
<i>Caster chair test</i> (Test method: EN 985)	: NA
<i>Impact sound reduction</i> (Test method: NA)	: NA
<i>Thermal resistance</i> (Test method: NA)	: 0,60 togs - 0,06m ² K/W
<i>Fire retardency</i> (Test methode: EN ISO 9239-1)	: NA
<i>ASTM radial panel test</i> (Test methode: ASTM E 648-06)	: NA
<i>Russian requirements on fire safety</i> (Test methode: FZ-123)	: NA

Installation instructions:

- Do not install Universal Stop on a recently coating coated floor. To prevent any chemical reactions between Universal Stop and the coating we advic least three months.
- make sure that the underfloor is absolutely dry and free of grit and dust.
- To cut the underpadding we recommend to use a scissors.

Important:

In case the installation has not been done in accordance with the installation instructions, estillon can not be held responsible for any damage or claim as a result of an incorrect installation. In case of doubt always consult your supplier.

